

How to:

POPCORN OPERATION INSTRUCTIONS

Popcorn machines typically have three switches:

- a) The kettle motor and exhaust which powers the kettle.
- b) The heat switch, which heats the kettle.
- c) The light switch, which operates the light inside the machine.

1. Turn all switches on.
2. For first batch only, allow kettle to warm up for aprox. 4 minutes.
3. Load pre-measured oil into kettle. If oil is solid, warm in kettle for 2 minutes.
4. Add pre-measured corn into kettle. Close lid and allow to pop.
Use only one packet of pre-measured corn at a time.
5. Popcorn will start opening kettle lid and fall on bottom of machine.
6. Listen for popping sound to stop. Dump kettle immediately after popping stops or kettle will burn. For burnt corn or excessive smoke, turn kettle heat off for 2 minutes.
7. Repeat steps 4 thru 7 and enjoy! Remember to always pop at least 5 batches each time machine is used. Keep both kettle switches off when not popping.
8. When popping last batch, turn kettle heat switch off as soon as corn starts popping rapidly.



Peter Corvallis Productions

S I N C E 1 9 5 9